

First Transitional Shophouse Style

A general lightening of expression can be discerned in this style due to the greater height of each storey. Windows and doors are usually timber-shuttered although small plates of glass in the shutters became increasingly common. There are often two windows on the upper storeys and transoms are flat-arched, semi-circular or rectangular infilled with timber-framed glass, cast iron or carved timber panels.

